Instrument Overview

Yosuke Minowa, Takashi Hattori (Subaru Telescope, NAOJ)

6/16/2016 ULTIMATE-Subaru Science Workshop 2016

ULTIMATE-Subaru instrument plans

- 1) Wide-field imager
- 2) Multi-object integral field spectrograph
- 3) Multi-slit spectrograph

	Imager	MOS	Multi-Object IFU ^a	
Wavelength Coverage	$0.8-2.5 \mu$	$0.9{-}1.8~\mu{\rm m}$		
Plate Scale	0.10 arcsec	0.15 arcsec/spaxel		
FOV	ϕ =16'	$\phi = 6' - 16'^{\text{b}}$	IFU: 1".18×1".18,	
		(TBD)	Patrol area: $\phi \sim 15'$	
Filters	$YJHK + NBF/MBF/TBF^{c}$	HK + NBF/MBF/TBF ^c —		
Spectral Resolution	ution $ \sim 3000 (0".4 slit)$		500-3000	
Multiplicity	_	$\sim 100 \text{ slits (TBD)}$	8-13 IFUs (TBD)	
Detector	$4 \times H4RG(Teledyne)$		$2 \times H2RG(Teledyne)$	
Efficciency ^d	$\sim 48\% ({ m J,H}), {\sim} 40\% ({ m K})$	${\sim}33\%({ m J}), {\sim}35\%({ m H,K})$	~7%(J),~10%(H)	

^a In case of using MOIRCS as a spectrograph.

^b FoV will be limited to 6' if the instrument is installed at NsIR.

^c NBF, MBF, and TBF indicate narrow-band, medium-band, and tunable filters, respectively.

^d Total Efficiency includes atmosphere, telescope, and instrument (optics + detector).

Wide-Field imager: Baseline Specification


Wavelength coverage	0.8-2.5um	
Plate scale	o.10"/pix (TBD)	1pix=15um
FoV	φ < 16 arcmin	Separation of 4 areas TBD
Filters	BB / MB / NB (+ tunable filter ?)	See example in the fact sheet
Detectors	4 H4RGs (4k x 4k)	


The WFI is currently 1st priority instrument among the three instrument plans for ULTIMATE.

Wide-Field Imager: Conceptual optical design

Design	J. Pazder (HIA)	T. Yamamuro (OptCraft)	T. Yamamuro (OptCraft)	Y. Tanaka (Subaru)
Date	5/29/2013	3/30/2012	3/15/2013	9/29/2015
FoV	Ф20' (6'.8 x 6'.8 x 4)	Ф12'.6	11'.5 x 11'.5 x 4	Ф16'
Scale	0".1/pixel	0".08/pixel	0".08/pixel	0".077/pixel
Lens	14	19	21	8 + 2 mirrors
Purpose	design concept	MOS design	MOS design with FoV split	compact imager with a large spherical mirror
Note		FoV limited by Φ400mm CaF2	FoV limited by Φ400mm CaF2, feasibility problem	
Layout	Camera #1 GET derECom GET man (Figure 1) GE	Total Parison Total T	The state of the s	Design 1 1145mm Cs focal position
Spot Diagram	< ~0".1 Compared to the com	C*0".15	<~0".16 but up to 0".27 at edge	Column of the second of the se


Four Barrel Imager Design (J. Pazder, HIA)





Four Barrel Imager Design (J. Pazder, HIA)

- each unit has 6'.8 x 6'.8 FoV (0".1/pixel with H4RG)
- good imaging performance (RMS diameter < ~1pixel=0".1)



Tunable filter for imager

- Alternative to NB filter set
- Fabry-Perot etalon
 - there were activities in developing cryogenic etalons
 - F2T2 (Flamingos-2 Tandem Tunable filter)
 - TFI (Tunable Filter Imager) for JWST
 - cryogenic and large aperture etalon may be challenging
 - feasibility and expected performance are under study
 - discussing with COM DEV Canada

Instrument	F2T2	JWST-TFI	ULTIMATE
spectral resolution	>800 (wing suppressed)	100	~100?
wavelength	0.95-1.35μm	1.5-5μm	0.8-2.5μm
field of view	50"-1'.5	2'.2	~16'
operating temperature	~110K	~35K	~120K
aperture size 60mm		56mm	~100mm
location	telescope focus	pupil	pupil

Multi-Object IFU spectrograph: Baseline Specification


Conceptual design by Australian Astronomical Observatory (AAO)

- Fiber-bundle IFU with Starbug positioners
- Re-use MOIRCS for initial phase observation.
- Develop a dedicated spectrograph to increase the number of IFUs and optimize the optical parameters


IFUs			
Number of IFUs	8-13 ^a		
Number of elements per IFU	61 Hexagonally packed		
Spatial sampling per element	0.15 arcsec		
Total field of view per IFU	1.18 square arcsec		
Total patrol area	$\phi \sim 15 \text{ arcmin}^{\text{b}}$		
Minimum separation between IFUs	25 arcsec		
Spectrograph (MOIRCS)			
Wavelength coverage $0.9\text{-}1.8 \ \mu\mathrm{m}$			
Spectral resolving power	500-3000		
Dispersion	1.6 \mathring{A} per pix (J) , 2.1 \mathring{A} per pix (H)		
Sampling	2-5 pixels in FWHM		
Combined properties			
Total efficiency	9% (J), 12% (H)		

Simon Ellis et al.


Multi-Object IFU spectrograph Fiber bundle IFU with Starbug positioners



Multi-Object IFU spectrograph Fiber bundle IFU with Starbug positioners



Multi-Object IFU spectrograph Fiber bundle IFU with Starbug positioners



Multi-Object Slit spectrograph: Baseline Specification

Wavelength coverage	0.8-2.5um	
Plate scale	0.10"/pix (TBD)	
FoV	6' – 16' (TBD)	
Spectral resolution	~3000 (0.4" slit)	
Multiplicity	~100 slits	
Efficiency	~33% (J), ~35% (H,K)	


- The Specification of the Multi-Slit Spectrograph has not been studied yet.
- Currently, "Keck/MOSFIRE" like spectrograph is assumed.
- There is an idea to use "MOIRCS" as a first light instrument for GLAO.

Multi-Object Slit Spectrograph

Design	T. Yamamuro (OptCraft)	T. Yamamuro (OptCraft)	Y. Tanaka (Subaru)	IRMS
Date	3/30/2012	3/15/2013	9/29/2015	?
FoV	Ф12'.6	11'.5 x 11'.5 x 4	Ф16'	Ф6'
Scale	0".08/pixel	0".08/pixel	0".088/pixel	0".25/pixel
Lens	19	21	16	15
Multiplicity	50-100?	50-100?	50-100?	36
Resolution	R~3000	R~3000	?	R~6300
Note	FoV limited by Φ400mm CaF2	FoV limited by Φ400mm CaF2, feasibility problem		Nasmyth focus
Layout	INCLINENT LIGHT TESTAND TO SERVICE AND THE SER		Design 4	Conting/Merror Enchange Dewn Outer Turet Window Dewn Lace Window FCS Merror Configurable Sit Unit (CSU) Filter Wheels Field Less


Wide-Field Near-IR Multi Object Spectrograph Conceptual Optical design (T. Yamamuro, OptCraft)

Design	I-A-1	I-A-2	I-B-1	II-A	II-B
M2	current	current	new	current	new
M1 shapre	current	current	new	new	new
FoV	Ф13'.2	Ф12'.6	Ф16'.2	8'.5x8'.5x4	11'.5x11'.5x4
Field flattener	no	yes	yes	yes	yes
Lens	17	19	19	21	21



Wide-Field Near-IR Multi Object Spectrograph Conceptual Optical design (T. Yamamuro, OptCraft)

- FoV (φ12'.6) is limited by D=400mm CaF2
- RMS diameter < 0".15 at most positions and wavelengths
- mechanical and cryogenic feasibility studies are needed



MOIRCS as a first light instrument


MOIRCS specification:


- Imaging ... YJHKs & 11 NB filters, 4'x7' fov.
- MOS Spectroscopy ... Low-resolution (ZYJH & HK: R~500) and the VPH medium-resolution (R2000-3400) are available.
 - It is almost impossible to develop 3 instruments at the same time.
 - Use MOIRCS as a first light instrument (imager and spectrograph) for GLAO, as suggested by the reviewers during the external review on Feb.
 - By using GLAO, MOIRCS sensitivity can be similar to or even higher than MOSFIRE with much better spatial resolution (0".5 \rightarrow 0".2).


MOIRCS Upgrade (nuMOIRCS)

2015: Detectors Upgrade Completed!

- 2 Hawaii-2 RG + Sidecar ASIC, SAM controller.
- Good readnoise (5e- by 10 multi-sampling)
- Better total efficiency








MOIRCS Upgrade (nuMOIRCS)

- 2017 (?) MLA IFU Installation (Ishigaki-san in Iwate Univ.) is being planned.
- New Grism development project is (→ Ebizuka san's Talk).




MLA IFU Specification

Spatial Sampling 0.2 arcsec

MLA format 9 x 31 lenses

Field-of-view 1.8arcsecx 6.2 arcsec

Diffraction Efficiency of SR Grism #2c



R~1400 Hybrid Grism Design (an example)

Summary

- Wide-Field Imager
 - good image quality (~0".1) over wide FoV (16'-20')
 - opt-mechanical feasibility studies are planned
- Multi-Object Integral Field Spectrograph
 - can utilize existing instrument MOIRCS and the large FoV of new GLAO system
 - difficulty in K-band
- Multi-Object Spectrograph
 - Further investigation to use MOIRCS as a first light instrument.
 - Need some more investigation for new instrument with single FoV cases (ϕ ~13')